



MODE D'EMPLOI
TECHNICAL MANUAL
BEDIENUNGSANLEITUNG
MODO DE EMPLEO
GEBRUIKSAANWIJZING
ISTRUZIONI PER L'USO

Armoires à vins

Wine cabinets

Weinklimaschränke

Armarios para vinos

Wijnkasten

Armadi climatizzati per vini

Gamme-Range-Aufbewahrungsserie-Gama-Gamma

Elégance

Loft
Villa
Bastide



Warning

The information in this document is subject to modification prior notice.

TRANSTHERM offers no guarantee on this equipment item if it is used for any specific purpose other than that for which it was designed.

TRANSTHERM cannot be held responsible for any errors in this manual, nor for any damage linked to or following the provision, performance or use of the equipment item.

This document contains original information, protected by copyright. All rights are reserved. All photocopying, reproduction, translation, whether partial or total, are strictly prohibited, without prior written consent from TRANSTHERM.

TRANSTHERM


24, rue Francis de Pressensé - 69628 Villeurbanne cedex - France

Contents

1	- Description of your wine cabinet	P 4
2	- Installing your wine cabinet	P 5
3	- Layout and loading recommendations.....	P 6/7
4	- Commissioning and temperature settings	P 8/9
5	- Important wine information	P 9
6	- Wine service temperatures.....	P 10
7	- Everyday wine cabinet maintenance	P 11
8	- Operating anomalies	P 12
9	- Technical characteristics.....	P 11
10	- Frequently asked question	P14/15
11	- Protecting the environment.....	P16

GB

Description of your wine cabinet



- | | |
|---|------------------------------|
| 1 Cabinet body | 5 Setting strip |
| 2 Hinge | 6 Lock |
| 3 Glass door or solid door (depending on model) | 7 Adjustable foot (4) |
| 4 Storage shelf (type version) or universal sliding shelf | 8 Thermodynamic pump orifice |
| | 9 Maker's label |

Installing your wine cabinet

When unpacking your cabinet, make sure that there are no traces of impact or deformation and that there are no surface defects.

Carefully remove all of the protections and adhesive strips from the packaging around your wine cabinet.

Open the door and make sure all components are intact.

Release the electrical lead.

Move your cabinet to its final location.

The place you have selected for your cabinet should:


Recommendation

- Be unencumbered and well ventilated,
- Enable a minimum 10 cm space between the wall and the back of the cabinet,
- Be well away from any heat source,
- Not be too damp (laundry, pantry, bathroom, etc.),
- Have a solid and flat floor,
- Have a standard and accessible electricity supply (standard socket to country standards, linked to ground with differential trip),
- It is NOT recommended to use a multi-socket or extension lead.


GB

Installing the handle

Installing the handle of your wine cabinet is carried out in the following manner:



- Introduce the two spacers (B) into the holes on the inside panel of the door.
- Add the two washers (C)
- Using a screwdriver, secure the handle (A) with the two screws (D).
- Clip the two knobs (E) onto the washers.



important →

In order for you to level off your cabinet as easily as possible, it is equipped with 4 adjustable feet. However, we do recommend that you tighten the back feet to the maximum and use the front feet to create a level (a spirit level is recommended for this operation).



WAIT 48 HOURS BEFORE PLUGGING IN THE CABINET

Should you need to move your cabinet, never tilt it more than 45° and always sideways, on the side that the electrical cable comes out (right hand side when looking at the cabinet).

Layout and loading recommendations

All shelves can be used as storage, sliding or presentation shelves. Your cabinet's shelves have 13 recesses allowing you to store your bottles in complete safety.

Storage rack





To install bottles on a storage shelf:

- Insert the shelf at the desired position.
- Place a wooden locking pin in each of the 2 holes located on the right and left side of the upper face approximately 15 cm to the front of the shelf: these pins secure the shelf to the thermoformed wall and prevent any inappropriate movement (see diagram).
- Start by placing the bottles in each recess on the back row, with the base of the bottle towards the back.
- Continue with the front row, placing the bottles in the opposite direction.
- Continue stacking the bottles, ensuring that none of the bottles touches the back wall.

A storage shelf can hold a maximum of 6 rows of 13 bottles, or 78 traditional Bordeaux type bottles (100 kg).

Configuration of a shelf in presentation layout:



To install bottles on a presentation shelf:

Insert the shelf at the desired position.


Place a wooden locking pin in each of the 2 holes located on the right and left side of the upper face approximately 15 cm from the front of the shelf: these pins secure the shelf to the thermoformed wall and prevent any inappropriate movement (see diagram).

- Start by placing the bottles in each recess on the back row, with the base of the bottle towards the back. (6 traditional Bordeaux type bottles).
- Continue stacking the bottles on the back row ($7 + 6 + 7 + 6 = 26$ traditional Bordeaux type bottles), ensuring that none of the bottles touches the back wall.
- To present your bottles, place them in a vertical position on the front of the shelf (maximum capacity: 6 traditional Bordeaux type bottles).

When in presentation layout, the shelf has a maximum capacity of 38 traditional Bordeaux type bottles.

Shelf in sliding version configuration:

To place bottles on a sliding shelf, carry out the following:



- Install the shelf in the selected location.
- Place a wooden locking pin in each of the two holes located on the right and left of the upper face approximately 4cm to the rear of the shelf: when the shelf is slid forwards, these pins stop it from sliding completely out of the cabinet (See diagram).
- Start by placing the bottles in the rear recesses with the base of the bottles towards the back.
- Continue by placing the bottles in the front recesses facing them in the opposite direction.

- A sliding shelf can only hold one layer of bottles (maximum of 13 "Tradition" Bordeaux bottles).

- In order to enjoy optimum accessibility when setting up the cabinet in a mixed layout, we recommend that shelves destined to be used as sliding shelves are located in the middle section of the cabinet.

NEVER SLIDE MORE THAN ONE SHELF.

Recommendation

You should remember that if you do not have enough bottles to fill your wine cabinet, it is better to distribute the load over all of the shelves available, so as to avoid "all on top" or "all below" type loads.



Rearrange the locking pins when changing from sliding shelf to storage or presentation shelf.

important →

The shelves all have a label slot, designed to receive the pre-cut cards delivered with your cabinet, thus helping you to identify the position of your favourite wines at a glance.

GB

Commissioning and Temperatures settings



1 • Commissioning

- **Once you have waited 48 hours, connect your cabinet to the mains**, having checked that there is power to the socket (check fuses and their amperage, the state of the trip, and if necessary try out another electrical appliance to verify the supply).
- Once connected to the mains, make sure that the Off/On switch, on the right of your cabinet's control panel, is set at "On" (I).



2 • Temperature settings

The temperature control(s) and setting(s) are adjusted from your wine cabinet's settings panel, as shown below:



- Temperature display: Displays the current temperature inside your wine cabinet.
- Adjustment button (SET 1/ SET 2/probe): sets the desired temperature inside the cabinet.
- On/off button: switches the wine cabinet on and off.

To adjust the temperature of your cabinet:

- Press button SET 1 or SET 2, the symbol $^{\circ}$ appears.
- Press the Probe button to make the previous setting appear.
- Set the desired temperature using the SET 1 and SET 2 buttons.
- Confirm your programming by pressing the Probe button.

The recommended control range for maturing your wine is from 42°F to 64°F, the default setting is 54°F.



To operate correctly, your cabinet should be located in a room with a temperature between 32°F and 95°F.

When there has been a significant modification in set temperatures, it can take several hours for your wine cabinet to stabilise and display the desired temperature.

GB

Important wine information



Your TRANSTHERM cabinet has been designed to guarantee the optimum conditions for storing and/or serving your wine

Wine is a highly complex product, requiring long and gentle development and needs specific conditions in which to reach its full potential.

All wine is stored at the same temperature, only the temperatures for serving and wine tasting can vary depending on the type of wine (see the table)

This being the case and just like the natural caves used by wine producers, it is not the exact temperature that is important, but its constancy. In other words, as long as the temperature of your cabinet is between 10 and 14° C, your wine will be stored in perfect conditions if the temperature is not subject to any significant fluctuation

However, it is advisable to be especially careful concerning the values shown on your wine cabinet's hygrometer, which, due to its location in the wine cellar will always have tendency to display a lower humidity level.

IRRESPECTIVE OF THE CAUSE, IF YOU NOTICE EITHER ABNORMAL TEMPERATURE OR HUMIDITY LEVELS INSIDE YOUR CABINET, BE REASSURED THAT ONLY LONG EXPOSURE TO THESE ABNORMAL CONDITIONS CAN HAVE A DETRIMENTAL EFFECT ON YOUR WINES.



Wine service temperatures (provided as an indicator only)

French wines

Alsace	10°C
Beaujolais	13°C
Sweet white Bordeaux	6°C
Dry white Bordeaux	8°C
Red Bordeaux	17°C
White Burgundy	11°C
Red Burgundy	18°C
Champagne	6°C
Jura	10°C
Languedoc-Roussillon	13°C
Provence Rosé	12°C
Savoie	9°C
Dry White Loire Wines	10°C
Sweet White Loire Wines	7°C
Red Loire Wines	14°C
Rhône wines	15°C
Sweet South-West wines	7°C
Red South West Wines	15°C

Australian wines

Cabernet franc	16°C
Cabernet sauvignon	17°C
Chardonnay	10°C
Merlot	17°C
Small grape Muscat	6°C
Pinot noir	15°C
White Sauvignon	8°C
Semillon	8°C
Shiraz	18°C
Verdhelo	7°C

Other wines

Californian	16°C
Chilean	15°C
Spanish	17°C
Italian	16°C

Everyday care of your wine cabinet

Your TRANSTHERM cabinet is a simple tried and tested item of equipment. The following few operations enable you to obtain optimum operation and an extended life cycle.

- 1 -Regularly remove dust (once a year) from the condenser (black metal grill fastened to the back of your wine cabinet).
- 2 -Completely clean the inside of your wine cabinet once a year, taking care to ensure that you have unplugged and unloaded it (use water and a non caustic cleaning product, and make sure to rinse well).

GB

Nota **B**ene

Hygrometry

You cabinet is equipped with an exclusive TRANSTHERM system enabling the creation, inside your wine cabinet, of the correct humidity level required to perfectly seal the corks in your bottles

This system uses the water retrieved from condensation, which is then recycled. Should the humidity level in your cabinet ever reach critical level (less than 50%), just add one or two glasses of water to the lower tray of your cabinet.

Recommandation

The long life of your wine cabinet depends on regular monitoring, especially of anything that may appear abnormal, and informing us of any anomalies found.

Operating anomalies

When starting up

The compressor will not operate :

Ensure that there is power to the electrical supply plug by connecting another electrical appliance to it.

The compressor will not turn off:

1- Place your hand on the condenser (metal grill located along the exterior wall behind your cabinet). If the condenser is cold, get in touch with your retailer.

2- If the condenser is hot, turn the cold adjuster to its highest level, if the compressor does not stop, get in touch with your retailer.

important →

Any intervention on the cold circuit should be performed by a refrigeration technician, who should carry out an inspection of the circuit sealing system.

In the same way, any intervention on the electrical circuit should be performed by an electrician.

The power cable is fitted with an earthed plug standard to the country of consignment. It is essential that, for your safety, the electrical supply to the cabinet be earthed. Please have the suitability of the socket checked by a qualified electrician, who will make sure that it is properly earthed and, if necessary, repair it.



ONLY A QUALIFIED ELECTRICIAN SHOULD MAKE ANY REPAIRS OR INSPECTIONS TO YOUR ELECTRICAL SUPPLY.



THE USE OF GLASS DOORS HAS AN EFFECT ON PERFORMANCE.

Technical Characteristics

Model	Temperatures	Heigh	Width	Depth	Weight***	Precision
Loft	1	1110 mm	680 mm	680 mm	61 kg	+/- 1,5°C
Villa	1	1470 mm	680 mm	680 mm	71 kg	+/- 1,5°C
Bastide	1	1810 mm	680 mm	680 mm	82 kg	+/- 1,5°C

GB

Model	Electrical power****	Consumption*	Voltage**	Frequency**	Usage restrictions	
					T°mini	T°maxi
Loft	107 W	0,5 kW / 24 h	230 V	50 Hz	0°C	35°C
Villa	107 W	0,7 kW / 24 h	230 V	50 Hz	0°C	35°C
Bastide	107 W	0,7 kW / 24 h	230 V	50 Hz	0°C	35°C

* Measured with an exterior temperature of approximately 20°C

** Depending on country this may vary. For the specific values for your equipment item, please consult the maker's label on it.

*** Weight without racks

**** Measured with an exterior temperature of approximately 32°C

Frequently asked questions

I have noticed differences in temperature between the upper and lower section of my cabinet.

- Refer to the setting instructions.
- Check that none of the bottles is touching the back of the appliance. Please note, however, that only the temperature of the air varies. Liquids have a high degree of thermal inertia which prevents the wine from changing temperature.
As in a natural cellar, a deviation in temperature of about 2 to 3°C is considered normal owing to convection phenomena. The important factor for wine is that at any given moment, the temperature is constant.

I have noticed frost on the back of my cabinet.

In a Transtherm wine cabinet, frost may appear in the upper section on the left hand side of the back wall. It is coldest when the compressor starts up. This is therefore the time when the frost will be most noticeable – this is completely normal.
When the compressor stops the frost turns into water droplets.
If frost accumulates to the point of producing ice (because the bottles are touching the back wall) unplug the machine, wait for it to defrost then arrange the bottles correctly and plug it back in.
If, in spite of these precautions, ice (and not frost) develops again, it is essential that you contact your retailer's after-sales service.

What are the risks for my wine in case of extended power outage?

The Transtherm cabinet's insulation protects against extreme changes in temperature; thermal inertia linked to the volume of bottles considerably slows down changes in temperature. Should a power outage occur, the temperature will be restored very slowly in order to protect the wine from thermal shock. It is recommended that you avoid opening the cabinet during this time. Wine kept at an ambient temperature for a short period will not deteriorate.

My cabinet makes no noise.

The compressor fitted in Transtherm cabinets is very quiet (36dB). Depending on the ambient temperature of the room and the temperature of the cabinet, the compressor may have stopped according to the setting.

The level of humidity in my cabinet is too low.

Only a level of humidity which is very low over a long period of time is harmful (< than 50%)

Whilst the compressor is in operation a drop in humidity may occur, because of the transformation of humidity into frost. This drying of the air is only temporary and has no effect on the corks.

In case of persistent low humidity:

- Check that the hygrometer (not supplied) used to measure moisture is still correctly calibrated.
- Check that none of the bottles is touching the back wall of the cabinet.
- Check that the air inlet (shaft) is not obstructed.
- Pour the equivalent of a glass of water into the compartment which collects condensation water, if it is accessible, or into the bottom of the rear of the cabinet on the left hand side (condensation water evacuation pipe).

Where can I obtain additional shelves?

Depending on the model of your appliance, you can add shelves according to the desired layout.

The maximum number of shelves for each model is:

Loft: 6 shelves

Villa: 10 shelves

Bastide: 13 shelves

You can obtain additional shelves from your retailer.

GB

Protecting the Environment

Disposing of packaging:

The packaging used by Transtherm is manufactured using recyclable materials.

After unpacking your cabinet, take the packaging to a refuse collection point. For the most part, it will be recycled.

In accordance with legal provisions regarding protecting and caring for the environment, your wine cabinet contains no C.F.C.s.

To save energy:

- Install your cabinet in an appropriate place (see page 7) and within the recommended temperature ranges.
- Keep the door open for as short a time as possible.
- Ensure that the door seal is in good condition and check that it is not damaged. If it is damaged, contact your Transtherm retailer.

N.B.: Caring for the environment: when replacing your wine cabinet, consult the local municipal refuse department in order to observe the appropriate recycling procedure.

For refrigerant gases, substances and some parts in the wine cabinets, Transtherm uses recyclable materials which require a special packaging disposal procedure to be used.

Condemn the lock so that children cannot accidentally shut themselves inside the cabinet.

Place unusable appliances out of use by unplugging them and cutting the power supply.



Notes

GB

